
Box: PLOCK 1

BIKE	SUZUKI SV 650	PART NO.	ESI - 65
YEAR	1999 - ON	FIT KITS	OVAL Z039.11082 // ROUND Z039.10082
NOTES	Item 7 required to re-fit OE exhaust system	FEATURES	DB KILLER Z038.10120



- 1 450mm Silencer ESC 94
- 2 51-55mm Band Clamp (Z016.10002)
- 3 Composite Silencer Strap (R-Z038.10089)(O-Z038.10088)
- 4 2 x M8 x 25mm Washers (Z017.10825)
- 5 Connecting Pipe CP 325
- 6 55-59mm Band Clamp (Z016.10004)
- 7 Re-connecting Sleeve CP327

8 Original Silencer Cut Diagram

E-MARK	SCDB-UC e4 2106
ISSUE NO.	13
DATE	07/08/09
AUTHORISED	S.Northrop
CHECKED	

NOTE: ENSURE SCORPION SYSTEM IS CLEAR OF MOVING PARTS AND ALL ORIGINAL FUNCTIONS WORK CORRECTLY.




- A) Remove original exhaust from bike, taking care to keep all original components in a safe place.
- B) Refit Scorpion exhaust as per line diagram above.
- C) When fitted take bike for a short ride to ensure all functions are correct.
- D) When bike & exhaust are cool enough check all nuts and bolts are still secure.



Box F	V 1

BIKE	SUZUKI SV 650	PART NO.	ESI - 65
YEAR	1999 - ON	FIT KITS	OVAL Z039.11082 // ROUND Z039.10082
NOTES	PIPEWORK CUTTING INSTRUCTIONS	FEATURES	DB KILLER Z038.10120



- 1 Use correct tools and check parts list
- 2 Saw off standard silencer 65mm back from weld in pipework,(as illustrated) Clean sawn edge.
- 3 Connector pipe CP-327 should only be used to re-fit std silencer if required.
- 4 Use rubber strap under silencer bracket to prevent damage to silencer
- 5 Use a small amount of silicone to seal joints
- 6 Tighten all fasteners and check that it is clear of all moving parts, & all original functions are working correctly
- 7 Ride for a short distance and re-tighten all fasteners

E-MARK ROUND	
E-MARK OVAL	
ISSUE NO.	10
DATE	11/06/08
AUTHORISED	S.Northrop
CHECKED	

NOTE: ENSURE SCORPION SYSTEM IS CLEAR OF MOVING PARTS AND ALL ORIGINAL FUNCTIONS WORK CORRECTLY.